

COMPOTITE WAX RING

SUPPLIES AND TOOLS NEEDED

- ◇ Compotite Wax Ring
- ◇ Toilet flange
- ◇ Toilet bowl
- ◇ Adjustable wrench
- ◇ Disposable gloves
- ◇ Rag or sponge
- ◇ Bucket (for water)
- ◇ Putty knife (for old wax removal)
- ◇ Level (optional, for ensuring proper toilet placement)



STEP-BY-STEP INSTALLATION

(skip to step 4 if placing a new toilet vs replacing)

1. Prepare the Toilet Flange

- ◇ Turn off the water supply to the toilet and flush to remove as much water as possible.
- ◇ Disconnect the water supply line from the toilet tank.
- ◇ Remove the toilet by unscrewing the bolts at the base and gently lifting it off the flange.
- ◇ Use a rag to plug the flange opening to prevent sewer gases from escaping.

2. Clean the Flange and Area

- ◇ Scrape away any old wax residue from the flange using a putty knife.
- ◇ Clean the area around the flange with a rag or sponge to ensure a smooth and debris-free surface.

3. Inspect the Flange

- ◇ Check that the toilet flange is in good condition and level with the finished floor.
- ◇ Replace or repair the flange if it is damaged or sits too high/low.

4. Position the Compotite Wax Ring

- ◇ Remove the rag from the flange opening.
- ◇ Place the Compotite Wax Ring directly on the flange, ensuring it is centered over the opening.
- ◇ Apply gentle pressure to secure it in place.
- ◇ Alternatively, you can press the wax ring onto the bottom of the toilet bowl outlet instead of the flange.

5. Set the Toilet in Place

- ◇ Carefully lift the toilet and align the bowl outlet with the wax ring and flange opening.
- ◇ Lower the toilet straight down, ensuring the bolts on the flange pass through the holes in the toilet base.
- ◇ Apply firm, even pressure to seat the toilet into the wax ring, creating a watertight seal. Avoid rocking or tilting.

6. Secure the Toilet

- ◇ Hand-tighten the nuts onto the flange bolts, then use an adjustable wrench to snug them up.
- ◇ Do not overtighten, as this can crack the porcelain base.
- ◇ Verify that the toilet is level and adjust as needed by shimming the base.
- ◇ Reconnect the Water Supply
- ◇ Reattach the water supply line to the toilet tank.
- ◇ Turn on the water supply and allow the tank to fill.
- ◇ Test for Leaks
- ◇ Flush the toilet several times to ensure there are no leaks around the base or water supply.
- ◇ Inspect for proper sealing and address any issues if necessary.
- ◇ Clean Up and Finish
- ◇ Trim the excess length from the flange bolts if needed, and install decorative bolt caps.
- ◇ Clean the surrounding area and dispose of the old wax ring and other debris.

Proper installation of the Compotite Wax Ring ensures a long-lasting, leak-proof connection between the toilet and the waste pipe, maintaining the integrity of the tiled bathroom floor.